



## Quick Installation Guide

### AeroLAN™ Wireless PCMCIA Adapter

Models: AL1211

AL1211-DP

AL1011-PC

AL1011-DP



Making Networking Simple

### Introduction

Thank you for purchasing an Asanté FriendlyNET AeroLAN PCMCIA Wireless Adapter. This adapter is designed to be the most economical way to add wireless functionality to your small business or home office network.

- Works with Asante FriendlyNET wireless routers, Apple AirPort and other IEEE 802.11b devices
- Extend signal range with optional external antenna\*
- Protects your portable computer from damage with detachable antenna (AL1211/AL1211-DP only)
- Transfer data at 11 Mbps rate with advanced data encryption
- Dual-Platform support, drivers for Mac OS and Windows. (AL1211-DP/AL1011-DP only)
- Free telephone technical support when used with Microsoft Windows 98SE/Me/NT/2000/XP and Mac OS 8.6 through 9.x, OS X.1.3

### Packing List

Your package contains the following items:

- FriendlyNET AeroLAN PCMCIA Wireless Adapter
- This Quick Installation Guide
- Drivers Utility CD-ROM


### System Requirements

- **Macintosh Minimum Requirements:**  
Apple PowerBook 3400 running Mac OS 8.6 through 9.x, OS X.1.3 with 64MB RAM. (AL1211-DP/AL1011-DP only)
- **PC Minimum Requirements:**  
Pentium class computer with 64 MB RAM; Microsoft Windows 98SE/Me/NT/2000/XP. (All models)

\*Please see [asante.com](http://asante.com) for details

### Hardware Installation:


Here's how to install this adapter:



### Installing the Adapter into a laptop

1. Turn off the power to the laptop.
2. Insert the PC card into any available PC Card slot in your laptop.
3. Turn on the power to your computer and allow the computer to start up to the desktop.

### After rebooting, attach antenna into the adapter and run the wireless configuration utility.



### In a few moments, you will see the status of your AeroLAN adapter:

- Wireless Status (AL1011-PC/AL1011-DP Only) - Green LED flashes when searching for wireless connection. Green LED on when wireless connection has been properly established.

### Software Installation:

Follow the steps below to install the device driver and wireless configuration utility for the AeroLAN Wireless Adapter.

### Driver Installation:

1. Follow the hardware installation instruction to install the AeroLAN adapter into your laptop computer and insert the provided driver utility CD into your CD-ROM drive.
  - a. **Windows** – follow the Hardware Installation Wizard and locate the driver on the CD-ROM.
  - b. **Macintosh** – locate the Installer in the Macintosh folder on the CD-ROM and follow the on-screen instructions.
3. Reboot the computer.

### Installing AeroLAN Wireless Configuration Utility (Windows only)

- The AeroLAN Wireless Utility is automatically installed after the device driver has been properly loaded. After rebooting the computer, locate the AeroLAN logo located in Windows' system tray to launch the utility.

Visit Asanté at [www.asante.com](http://www.asante.com)

### Main Corporate Telephone Numbers

800-662-9686 (Home/Office Solutions)  
800-303-9121 (Enterprise Solutions)  
408-435-8388

### Technical Support

801-566-8991 (Worldwide)

### Technical Support Fax

801-566-3787



Making Networking Simple

Copyright © 2002 Asanté Technologies, Inc. Asanté and FriendlyNET are registered trademarks of Asanté Technologies, Inc. AeroLAN, and the Asanté logo are trademarks of Asanté Technologies, Inc. All other brand names and products are trademarks or registered trademarks of their respective holders. All features and specifications are subject to change without prior notice. 06-00642-00, 04/02