

## RELEASE NOTES


Thank you for purchasing an Asanté Ethernet product! This document includes important information not yet described in the manual. Please read the READ ME FIRST file on the EtherTalk Installer diskette. It contains information on the latest version of the EtherTalk Installer software, software release notes and how to contact Asanté should you experience any problems. Asanté products work with Macintosh System Software 6.0.7 and above.

### About AsantéLite NuBus Cards

1. AsantéLite NuBus Ethernet adapters are compatible with all Macintosh computers with a NuBus slot. This includes the Performa 600, Centris 610, Centris 650 Quadra computers and the Duo Docking Station. ( NOTE: Installing AsantéLite NuBus adapter into a Centris 610, requires an Apple Centris 610 NuBus Adaptor, part number M1402LL/A).

### About Asanté AsantéLite LC Cards

1. AsantéLite LC Ethernet adapters are compatible with the Apple's Macintosh LCIII, LCII, LC, Color Classic and Performa 400 Series computers.
2. Motorola 68882 math co-processors for the LCIII should be placed on the motherboard only. The socket on the LCIII motherboard optimizes math co-processor performance.
3. If your Macintosh has a math co-processor on-board, do not install an AsantéLite LC adapter which also has a math co-processor. Your Macintosh can not work with two math co-processors present.
4. The AsantéLite LC Ethernet adapters feature a Link Integrity disable jumper. This allows the card to be used with non-compliant 10BaseT products. The jumper JP2 default setting is for Link Integrity ON. To disable Link Integrity, set the jumper as shown:



(more)

### **Asanté EtherTalk Installer Diskette**

The Asanté MacCon and FriendlyNet adapter products contain new Asanté network software. If your network contains more than one Asanté Macintosh Ethernet adapter, we recommend that you install the updated software on all appropriate computers with Asanté network adapters. Detailed instructions are in the READ ME FIRST file on the EtherTalk Installer diskette.

Note: The "Easy Install" option will install AppleTalk 57.04 on your Macintosh system. Before you install AppleTalk 57.04, check with your network administrator to verify that your software applications and network hardware is compatible with this version of AppleTalk.

If installation of AppleTalk is not required due to compatibility reasons, you **MUST** select the "Customize" option. Then, select and install only the appropriate Asanté software driver, leaving the installed version of AppleTalk, EtherTalk and Network cdev untouched.

### **Mail Us Your Registration for 5-year Warranty**

Please mail in your product registration card today to activate the warranty and receive free technical support. All Asanté network adapters are backed by a 5-year warranty. By returning your registration card you will also receive new information on updates and new products.

### **Package Contents of MacCon NuBus Family Products**

- AsantéLite NuBus Ethernet adapter card
- AsantéLiteinstallation manual
- Unshielded twisted-pair cable (AsantéLite NB-10T only)
- BNC T-connector (AsantéLite NB-TN only)
- Asanté EtherTalk Installer diskette
- Registration card

### **Package Contents of FriendlyNet NuBus Family Products**

- AsantéLite LC Ethernet adapter card
- AsantéLiteinstallation manual
- Unshielded twisted-pair cable (AsantéLite LC-10T only)
- BNC T-connector (AsantéLite LC-TN only)
- Asanté EtherTalk Installer diskette
- Registration card

If any of the above items are missing, please call Asanté RMA Department at 800-622-7464.