



FriendlyShare™ software **(For Macintosh Installation)**

READ ME FIRST!

CD-Rom

This CD-Rom Contains

- 1. *FriendlyShare™* Manual**
- 2. *FriendlyShare™* Software**
- 3. WhatRoute Troubleshooting software**
- 4. *FriendlyShare™* Data Sheet**
- 5. Asanté™ Solutions Guide**
- 6. Adobe™ Reader Installer**

Quick Start:

- 1.** Before installing *FriendlyShare™* make sure that you have a working ISP connection for the computer you will be using as the server for your LAN (Local Area Network).
- 2.** Make sure you have a functional Local Area Network, and that the server has a working Ethernet connection.
- 3.** Install the *FriendlyShare™* IP sharing software on the server computer of your LAN. Please be sure to follow the *FriendlyShare™* installation instructions carefully.
 - Do not install *FriendlyShare™* on the client computer. *FriendlyShare™* installed on the server will assign an IP address to the client computer automatically.
- 4.** Configure the client computers on your LAN to get their IP addresses using DHCP. See the *FriendlyShare™* manual for more information on configuring the client computers.