

AsantéFAST 100 Hub™

READ ME FIRST

Cascading hubs

The recommended procedure for cascading two AsantéFAST 100 Hubs is to connect a Category 5 UTP cable from the **Uplink** port on the first hub to any **RJ45** port on the second hub.



The Uplink port on the AsantéFAST 100 Hub is provided solely for the purpose of cascading hubs.



Attempting to cascade hubs using any other method may result in abnormal port behavior.

For more information on cascading hubs, see step 6 of the AsantéFAST 100 Hub Fast Guide.