



## Read Me First

# 100FX MII Module for the IntraSwitch 6216M

---

### Asanté Technologies Product Release Notes and installation Notes for the 100FX Module for the IntraSwitch 6216M

---

Thank you for purchasing the Asanté IntraSwitch 6216M and the 100FX MII module. Before you install your Asanté MII module for this switch please read this sheet carefully for configuration and operating recommendations.

The Asanté MII module will work in “hot mode” without requiring a unit power down but Asanté recommends that changes to your network be made while the system is down, if possible.

#### To install:

- Power down the unit.
- Simply remove rear cover panel for the slot into which you wish to place the Asanté MII module.
- Insert module into the guide rails and slide in until you meet resistance.
- Push firmly until the connector seats.
- Lock in with thumb screw.
- Insert Fiber connector.
- Power up the unit.

#### Duplex Settings:

The Asanté FX MII is not auto-negotiation and will only operate at 100Mbps Full or Half duplex.

#### Default settings:

The default setting of the Asanté MII FX module is 100Mbps Half duplex. If you want to change the setting this can be done in the port configuration menu or screen in the console/telnet or HTTP server.

#### Questions:

**If you should have any questions regarding the use or configuration of your new switch please call Asanté Technical support between the hours of 6 AM to 5 PM (Mountain Time) Monday through Friday at (800) 622-7464.**