

Thank you for purchasing an IntraCore Managed Gigabit Ethernet switch. This Release Note applies only to:

- **IC35160-T**
Part number: 99-00747-XX
Sub-assembly: 61-20747-01
- **IC35160-G**
Part number: 99-00716-XX
Sub-assembly: 61-20716-01

Version History

- 2.01 July 2004: Initial release for Firmware 2.x
- 2.04 Dec 2004: Bugs fixed
- 2.05a March 2005: Bugs fixed

Firmware Version

This version obsoletes v2.04 and earlier. The new 2.05a image file name is:

- rt35160_205a.ima

md5sum = bc5ebe4b64a4fa566eb00e567a576d4e

Note: The md5 checksum is provided for file integrity purposes. It is strongly suggested that users who have downloaded this firmware from the Internet should run a checksum against the image code to verify it did not get corrupted during transfer/download. The md5sum utility can be found on Linux/Unix and OS X operating systems and a free utility can be obtained for Windows at <http://winmd5sum.solidblue.biz/>.

Installation and Configuration Notes

- The default IP of the switch is **192.168.0.1**
- The default username is **root**
- The default password is **Asante**

New Version 2.05 Features

None.

New MIB Support

None.

Bug Fixes and Enhancements

1. Memory corrupt when excessive IGMP reports (> 80 pkts/sec) packets are present in the network and IGMP is enabled.

Known Problems and Limitations

None.

Documentation

The CD-ROM includes this documentation in Adobe PDF format:

- Setup Guide
- User's Manual

See the **Documents** folder for more information.

Technical Support and Updates

For technical assistance or to download the latest documentation, visit www.asante.com/support