

Thank you for purchasing an IntraCore Managed Gigabit Ethernet switch. This Release Note applies only to:

- **IC35160-T**  
Part number: 99-00747-XX  
Sub-assembly: 61-20747-01
- **IC35160-G**  
Part number: 99-00716-XX  
Sub-assembly: 61-20716-01

#### *Version History*

- 2.01 July 2004: Initial release for Firmware 2.x
- 2.04 Dec 2004: Bugs fixed

---

### **Firmware Version**

This version obsoletes v2.01 and earlier. The new 2.04 image file name is:

- rt35160\_204.ima

**md5sum** = 7456592a34d60ff1cc73d5ab0dc7f78e

**Note:** The md5 checksum is provided for file integrity purposes. It is strongly suggested that users who have downloaded this firmware from the Internet should run a checksum against the image code to verify it did not get corrupted during transfer/download. The md5sum utility can be found on Linux/Unix and OS X operating systems and a free utility can be obtained for Windows at <http://winmd5sum.solidblue.biz/>.

---

### **Installation and Configuration Notes**

- The default IP of the switch is **192.168.0.1**
- The default username is **root**
- The default password is **Asante**

---

### **New Version 2.04 Features**

None.

---

### **New MIB Support**

None.

---

## Bug Fixes and Enhancements

1. Reduced the processing time of parsing the VLAN info in the configuration file.
2. Corrected a problem with IP multicast information in the configuration file not being processed.

---

## Known Problems and Limitations

None.

---

## Documentation

The CD-ROM includes this documentation in Adobe PDF format:

- Setup Guide
- User's Manual

See the **Documents** folder for more information.

---

## Technical Support and Updates

For technical assistance or to download the latest documentation, visit [www.asante.com/support](http://www.asante.com/support)