

Thank you for purchasing the Asanté FriendlyNET switch. This release note applies only to:

- **FriendlyNET GX5-2400W**
Part Number: 99-00814-XX.
Sub-assembly Number: 61-20814-00

Version History

- Version 1.0, November 2003, initial release

Installation Tips

In many cases, you may not need to configure this switch. Just plug in the network cables. Plug in the power cord. Turn on the power switch.

To configure this switch for advanced features (trunking, VLANs, mirroring and more):

- A. Manually set the IP address of your computer to the same subnet as the switch. For example, use an address like 192.168.123.1 for your computer; the default IP address of the switch is 192.168.123.253.
- B. From your web browser, open the switch's configuration page: **http://192.168.123.253**
- C. The switch's default password is **admin**

For more information, see the *User's Manual* on the CD.

Contents of CD-ROM

This CD contains:

- This *Release Note*
- *FriendlyNET GX5-2400W User's Manual*. Use Adobe Acrobat to view or print this document.
- GX5W Management Utility for Windows. Double-click on setup.exe to install this program.
- Asanté marketing materials (datasheets, product line guide, etc.)

Technical Support

For technical assistance or to download the latest firmware, visit www.asante.com/support