



Asanté Technologies, Inc.

AsantéFAST 10/100 PCI Adapter Card Rev. B

Read Me First !

Thank you for purchasing the AsantéFAST 10/100 PCI card (Rev. B). This is the installation note for the AsantéFAST PCI Rev. B open transport driver version 2.0. The following is a notice of manual CD installation requirements for the above referenced product:

1. Install the AsantéFAST PCI, carefully following proper grounding procedures.
2. Boot the computer and start Windows 95 or Windows 98.
3. Windows should autodetect the new hardware as PCI Ethernet Controller. Click "Next".
4. On the next window select "Search for the best driver for your device (Recommended)". Click "Next".
5. Insert the AsantéFAST 10/100 PCI Rev. B Adapter Driver CD-ROM. Click "Next".
6. Select "CD-ROM drive" and type in the drive letter for your CD-ROM drive. Click "Next".
7. Windows will find the "AsantéFAST 10/100 PCI Rev. B Adapter Driver CD-ROM". Click "Next".
8. Click OK on the next window as Windows displays "Please insert the disk labeled "AsantéFAST 10/100 PCI Rev. B Adapter Driver CD-ROM".
9. Windows will display "The file "L100W95.INF" on AsantéFAST 10/100 PCI Rev. B Adapter Driver CD-ROM cannot be found". Specify the correct path to your CD-ROM drive and click "OK".
10. Follow the on-screen instructions to finish the installation and restart the computer when installation is complete.

For additional installation details, a copy of the manual in pdf format can be found on the CD included with your AsantéFAST 10/100 PCI card.